

Hawker 800 AS REMOVED Parts for sale

Part Number	Description	Serial Number	Qty
064-1017-02	HF ANTENNA COUPLER POWER AMPLIFIER	16008	1
1056-01-12	RADIO TUNING UNIT	138	1
160240-600	SOUNDTRAND	375-0509	1
161043-701	ELECTRONIC SEQUENCE UNIT	7584-0208	1
2101822-1	AUTO POWER RESERVE CONTROLLER	107-101	1
2119010-8000	ELECTRONIC ENGINE CONTROL	96-BYD804	1
2119010-8000	ELECTRONIC ENGINE CONTROL	96-870795	1
25-8NF-4417-1A	PRESSURE TIME DELAY		1
25-DP5695	GASKET WINDOW	5021	1
31435/51539-006H	DC GENERATOR	96555	1
31435/51539-006H	DC GENERATOR	10725	1
31435/51539-006H	DC GENERATOR	92030	1
400-3279000	PASSENGER BRIEFING SYSTEM	9303057	1
501-1162-02	DIRECTISYN	1793	1
7517900-55	TCAS COMPUTER UNIT	99031739	1
822-0014-103	DATA BASE UNIT	1NRMT	1
M1050-L434-01	STEREO CHIME AUDIO SYS	9210011	1
130530-4	CABIN PRESSURE OUTFLOW VALVE CONTROLLER	46-125	1
2121-01-0013	OIL TEMPERATURE INDICATOR	B667225	1
2121-01-0014	OIL PRESSURE INDICATOR	BF53696	1
2121-01-0014	OIL PRESSURE INDICATOR	68273	1
25-8NF157-505	REFUEL PANEL ASSY	DH881236	1
25-8NF25-513	CONTROL PANEL	DM88/234	1
25-8NF5343-57A	EMERGENCY LIGHT CONTROL	DH6812	1
25-NF/23447-1A	APU CONTROL PANEL	8235	1
9-328-26	FUEL USED / FLOW RATE INDICATOR	2904	1
9-328-26	FUEL USED / FLOW RATE INDICATOR	1443	1
LT-52A	LIGHT DIMMER SUPPLY	15317	1
LT-52A	LIGHT DIMMER SUPPLY	10553	1
LT-52A	LIGHT DIMMER SUPPLY	11119	1
LT-52A	LIGHT DIMMER SUPPLY	11689	1
ND0075-1875	ELECTROSTACTI FILTER	1241236	1
WL656RSA2	N2 RPM INDICATOR	AK494	1
WL656RSA2	N2 RPM INDICATOR	AK493	1
WL717RSA3	N 1 RPM INDICATOR	AK597	1
WL717RSA3	N 1 RPM INDICATOR	AK994	1
WL718RSA3	ENGINE TEMPERATURE INDICATOR	AK767	1
WL718RSA3	ENGINE TEMPERATURE INDICATOR	AH222	1
011129	COOLING FAN	1943SE	1
10250A	RMI	4205	1
111-2	ACCELEROMETER	9702-0181	1
2132-1-11	FLAP POSITION INDICATOR	82338	1
21346-6	TEMPERATURE SENSOR	1151	1
25-8W5613-15A	LH COVER LENS ASSY		1
50-5011-02	METRIC ALTIMETER DIGITAL BUS INDICATOR	153	1
5400605-1	AUX RELAY BOX	117	1
5412600-25	THRUST REVERSE SWITCH	127	1
548408-1	I.T.T TEMPERATURE SENSOR		1
617452-3	AIR TEMPERATURE CONTROL	0776-104	1
622-8441-003	RECEIVER TRANSMITTER ANTENNA	1379	1
627578-1	TEMPERATURE CONTROL ZONE SELECTOR	022C-763	1
696-1-13	BRAKE PRESSURE INDICATOR		1

820-645	TEMPERATURE INDICATOR	522	1
93-A152-20	CVR Control w/ Microphone	25655	1
E-37040	PITO HEAT MONITOR	E2566	1
E-37040	PITO HEAT MONITOR	E2564	1
H221BLM	GYRON HORIZON	5456	1
K38002/1	BAROMETRIC	639	1
M877	DIGITAL LIGHTED CLOCK	11538	1
NF0075/667	ICE-DETECTOR	L248534	1
S4000-1	PASSENGER BRIEFING SYSTEM	9303073	1
SL27681	ANGLE ATTACK INDICATOR		1
TR9922-10	POWER UNIT	3616	1
TR9922-10	POWER UNIT	3617	1
WL-1901KD-1	FUEL QUANTITY INDICATOR	8993	1
WL-1901KLD-1	FUEL QUANTITY INDICATOR	971163	1
2118114-1-2	ENGINE SYNCHRONIZER	108-355	1
42-379	SKID CONTROL BRAKING SYSTEM	1022A	1
60-1755-1	STROBE LIGHT POWER SUPPLY	4385	1
60-1755-1	STROBE LIGHT POWER SUPPLY	6148	1
60-1755-1	STROBE LIGHT POWER SUPPLY	6220	1
C406	ELT	07755	1
CVR-30	COCKPIT VOICE RECORDER		1
E28180-10	OXYGEN GENERATOR	0649	1
M1285AC	CHIME TONE WARNING SYS	9208014	1
256NF79	PANEL	125	1
257CX285A	PANEL	636	1
25-8FN277-8	COCKPIT CENTER RH WINDOW BRACKET	DH589	1
25-8QF-191-5	COVER	675	1
25-8TF443-1	COVER	175	1
25-9DP861-7A	COVER	5926	1
25FC6095-5	COVER	16279	1
25FN11C1-1	COVER	650	1
25-W63679-1	FUEL TANK COVER	CH1200211C	1
25-W8-3708-2	FUEL TANK COVER	CH-10999H93	1
25WS3703-1	FUEL TANK COVER	CH09994-93C	1
25-WS3705-1	FUEL TANK COVER	CH0999489A	1
25-WS3706-2	FUEL TANK COVER	CH0999498A	1
25-WS3707-1	FUEL TANK COVER	CH0999H93A	1
25-WS3709-1	FUEL TANK COVER	CH0999493B	1
6225161-50	PANEL	802	1
1703-12	AIRFLOW ANGLE SENSOR	1489	1
257VF261A	AIR DUCT DISTRIBUTER		1
258VF263-63H	AIR DUCT HEAT EXCHANGER		1
25VF3633B	SILENCER		1
4202203	PUMP, HYDRAULIC	17992	1
4202203	PUMP, HYDRAULIC	AH-17798	1
AIR48540-1	VALVE ASSY SEQUENCE	904072	1
AIR48540-1	VALVE ASSY SEQUENCE	070407	1
01-0790044	RED POSITION LIGHT	05729	1
10	L-BAND ANTENNA	00160	1
106884-3-1	FLOW LIMITER	1114	1
1270-02	EXTERNAL CAPACITOR	2255	1
131052-1	AIR FLOW VENTURI	100-3682	1
1703-12	AIRFLOW ANGLE SENSOR	1118	1
1703-12	AIRFLOW ANGLE SENSOR	1373	1
1924-1	VALVE ASSY	111257-86197	1

1984-1	VALVE ASSY	M238VB712	1
2070C11	PUMP - FUEL BOOST	1640	1
25FO79005A-C	MAIN ENTRANCE DOOR ASSY	060	1
2B6-72OH	PUMP	8AH66	1
2C40-2	FUEL UMP	6AW144	1
30-0538-7	RED POSITION LIGHT	8707	1
320115C	AIR SHUTOFF VALVE	26451	1
34988-2	ROTARY ACTUATOR MOTOR BUTTERFLY		1
35170-4	ROTARY ACTUATOR	40-4840	1
67121-53-68	TEMPERATURE SNSOR	9212	1
9-127-55	FUEL FLOW TRANSMITTER	6491	1
AC61518	VALVE	294	1
AC67732	VALVE 4 PORT	35DT	1
AC67742	ACTUATOR	NG476	1
AIR48484/3	RH MLG DOOR JACK	LK8602459	1
AIR48485/3	LH MLG DOOR JACK		1
AL65218	MAXARET UNIT	67ER	1
C46BM10-100-5	ENGINE MOUNT ASSY	523	1
C46BM10100-6	ENGINE MOUNT ASSY		1
HTE9178-001	VALVE MOTORIZED	193SOV-109	1
HTE9178-001	VALVE MOTORIZED	9037	1
P18M-H14	OIL PRESSURE SWITCH	7122	1
SL27307	ANGLE OF ATTACK TRANSMITER	CS2009	1
0204KTU/2	FUEL QUANTITY	TU50870	1
0204KTU/2	FUEL QUANTITY	871	1
071-1271-01	EXTERNAL CAPACITOR	1659	1
10015	OXYGEN QUANTITY INDICATOR	F036	1
103278-13	SAFETY VALVE	23-650	1
103278-13	SAFETY VALVE	82623	1
104829001	ACTUATOR		1
131004-2	NEEDLE AIR VALVE ASSY	30-4629	1
132322-3-1	MOTOR DRIVEN VENTURI FAN	38157A	1
137847-1	Filter, Air	64547	1
208880-2-2	COOLING TURBINE	68-884	1
25FA37A/B	BOTTLE SILICA GEL		1
27441482	VALVE, ANTI-ICE SHUTOFF	7H0119	1
2893-9	APU FUEL DRAIN TANK		1
35170-8	ROTARY ACTUATOR	11-1205	1
540158-4-2	ROTARY ACTUATOR MOTOR BUTTERFLY VALVE	109-31886	1
5453612-1	HYDRAULIC ACTUATOR	016	1
622-5027-101	PRIMARY SERVO	172	1
AE4559	ROTARY VALVE ASSY	0402	1
AG64C-4	FLOW VALVE	65C	1
B-01-A214128A	SHUTOFF VALVE	T771	1
BA-02801-1	AC GENERATOR	1971	1
ENG19206	BLEED AIR CONTROL VALVE	WQN251H	1
ENG19207	BLEED AIR SOLENOIDE ASSY	WQM251M24	1
F903-7	DE-ICING FILTER	W13366-055	1
P067D075	ANTI-ICE PRESSURE SWITCH	AST92C256	1
WKA279422	OXYGEN VALVE	1036	1
WL1605AM2	ALTIMETRIC	AE577	1
25-6VF143-1	CABIN AIR DUT		1
25-7VF315A	DUCT		1
258VF27-1A	ELBOW	58372	1
25-8WS615-1	RH WING TIP POSITION LIGHT COVER	1162	1

25WS335/6	LANDING LIGHT COVER	DH3675	1
3001-112-900/400	OVERHEAT DETECTOR	69394	1
3001-133-900/500	OVERHEAT DETECTOR	94518	1
3001-133-900/500	OVERHEAT DETECTOR	2496	1
3071070-4	ENGINE MOUNT	99193	1
310C00200	TRANS SWITCH	4275	1
45352-100	DRAIN VALVE		1
55820-160493-201	APU SHROUD COVER	55820	1
55820SOCNA4950921	APU HOUR METER HARNESS WIRING	1774	1
622-5027-001	PRIMARY SERVO	2289	1
9006EN3	2X MICRO SWITCH	8824-14	1
91929	MICRO SWITCH ASSY	1323	1
ACM26274	PRESSURE STRUT	171	1
ACM26274	PRESSURE STRUT	85	1
D41721	ACTUATOR	13000278	1
LN9245-28-10-2	BALANCE FORCE RELAY & COOLING FAN ASSY		1
3AA2015	OXYGEN CYLINDER	1627	1
3AA2015	OXYGEN CYLINDER	2170	1
3AA2015	OXYGEN CYLINDER	25164	1
45774/3	HYDRAULIC CYLINDER	890911	1
45774/3	HYDRAULIC CYLINDER	8900023	1
AIR48502/6	ACTUATOR	APB020860	1
AIR48503	ACTUATOR	APB021210	1
0107KPU-1	PROCESSOR UNIT	XD10700	1
11129	COOLING FAN	1943SF	1
170099	OXYGEN OUTLET VALVE		1
25CCX283A	TRIM CONTROL	155	1
2854-11	MOUNTING ASSY		1
501-1075-02	EMERGENCY POWER SUPPLY - PS823B	4053	1
501-1075-02	EMERGENCY POWER SUPPLY -PS823B	G-1333	1
5400612-1	Relay Box	177	1
695-4-22	PRESSURE TRANSDUCER	5559-1-02	1
801A214128A	SHUT OFF VALVE	545	1
C-82106-5	SIGNAL SUMMING UNIT	630	1
C-82106-5	SIGNAL SUMMING UNIT	407	1
CB02701	GENERATOR CONTROL UNIT	1774	1
CB02701	GENERATOR CONTROL UNIT	1363	1
D3400	TEMPERATURE SENSOR	6024DA	1
DC10423-200	PERI-SEAL CONNECTOR	1471	1
LN9245-28-10-2	BALANCE FORCE RELAY & COOLING FAN ASSY		1
161798-1	SUMP PAN VALVE ASSY	55820	1
20094-1	VALVE ASSY		1
35150076	HYDRAULIC AUX TANK		1
364R704-2	REMOTE CONTROL TELEFLEX	58430-2	1
5843-1	REMOTE CONTROL TELEFLEX ASSY	78710	1
DH3760	STRUT	25CX7	1
FSC09049	HYDRAULIC TANK & valve assy	811	1
MS24166	EMP POWER INVERTER	7064	1
25-8FC1857-23A	FLOOR PANEL	2186	1
25FC1747-29	FLOOR PANEL	26277	1
25FC6197B	FLOOR PANEL	760	1